





M2

3V8

PWDN

SCK

GND

SDA0

SCL0

Cam_VDD

USB_ON/OFF

CLK2 DAT2

SD 2.0

SD 2.0

CARD1

CARD2

SIM1

- D2
- R18
- D3
- R19
- D7
- R20
- D5
- R21
- R22
- D6
- C18
- C17
- C15
- C13

- R10
- R9
- R16
- R14
- R12
- R11
- TP8
- DAT3
- TP22
- DAT7
- TP12
- DAT1
- TP11
- DAT0
- TP10
- CLK
- TP9
- CMD
- TP18
- VDD

- R63 R60
- C72 C71
- C70 C69
- R57 R59

- C68 C67
- R56 R58

- R64 R61
- U13
- C74 C73
- C66 C65
- U7
- R52 R55

- RST2 VDD2
- TP20
- TP17
- Q3

- TP14 VDD
- TP18 DAT
- TP16 CLK
- TP15 RST

- C62
- U12
- R50
- Q8

- C6
- C7
- C5
- C53
- C57
- C55
- C52
- C8
- D1
- C81
- U16
- C79
- C78

- C25
- L3
- C30
- L5
- C26
- C31
- C28
- C27
- R33
- R34
- R27
- R29
- C24
- C32
- C23
- C33

- Q9
- Q7